

# BACK POCKET DRILL

BPD4

Don SCBA from jump seat - ask one or more firefighters to don PPE (if not on) and proceed to apparatus.

FF's should immediately begin donning process as if on a response.

Seat belt is applied and maintained secured before beginning the donning process.

Critical steps identified below. If the FF does not perform satisfactorily the drill should be stopped and corrective action taken.

The FF should complete the drill and be ready to deploy as if arriving on the fireground as the first due attack engine.

## Critical Steps:

- Seat belt is applied
- Air is turned on
- Low air alarm is activated and acknowledge by the student
- PDD is activated
- Face piece seal is checked
- Face piece air connection is secured
- Bypass valve is operated
- Chin strap is on chin
- All snaps/straps/ buttons secured

